



888.372.1888

www.earphoneconnect.com

25139 Avenue Stanford
Valencia, CA 91355



MANUFACTURER'S LIMITED WARRANTY

Your Sales Receipt is required to validate & obtain warranty services.

Your unit is warranted against internal defects in material or workmanship. All of our earphones are warranted for 12 months. Hygiene restrictions prevent us from extending our limited warranty to wearable parts such as: Fin Ultra Ear Tips, Torpedo Earbuds, Nabs & ear inserts, etc.

The warranty is extended to the original purchaser only and does not cover the following:

- * Physical abuse
- * Damage from tugging or pulling
- * Improper maintenance of unit
- * Frayed, torn or exposed wires
- * Crushing or smashing in any way, shape or form

General misuse of the item such as: Excessive voltage, tampering with the unit or repairs attempted by someone other than the manufacturer will void the MANUFACTURER'S LIMITED WARRANTY.

The manufacturer reserves the right to evaluate and refuse warranty based on their evaluation. In order to obtain warranty services, proof of purchase in the form of a SALES RECEIPT must be returned along with the product.

For Returns Dept. & Return Authorization # Call Toll Free: (888) 372-1888.

After calling, send your return along with your name address &

Return Authorization number to:

The Earphone Connection, Inc.

25139 Avenue Stanford

Valencia, CA 91355

EARPHONE
CONNECTION

EPC MANUAL



www.earphoneconnect.com

Step 1. Make sure radio is off. Mount adapter to radio.

Step 2. Connect eartip to the acoustic tube for the desired side i.e., left or right ear.

Step 3. Wrap acoustic tube around ear and insert eartip to ear. Connect speaker to the back of collar or where you see fit. Attach microphone to the center mass on garment. Microphone should be about 8 inches from chin.


Note: It is suggested to have a buttonhole sewn on the shirt. It should be about 1 inch long on the seam.

Step 4. Run microphone cable inside garment and thread through pre-sewn buttonhole about an inch above the radio holster. Connect to radio adapter by lining about the guide arrow marks designated on the microphone cable and radio adapter.

Step 5. Turn on radio and slowly adjust volume to a comfortable level. Loud volume levels could cause harm to your ear.

FIN ULTRA INSTALLATION:

Insert the clear tube **elbow** into the small hole on the **back of the Fin Ultra**. Be sure to push the elbow all the way into the groove of the back of the Fin Ultra for a secure attachment.



Be sure to insert the flexible Fin Ultra deep into the contours of the ear cartilage for a secure fit.

To connect, grab the cable from the connector with the fore finger & thumb on either side of the guide arrow. Align the guide arrow with the alignment mark on the radio adapter and gently push down.

Easy-Connect:

Guide Arrow & Alignment Arrow are lined up.



To release, with the same two fingers grab the spring loaded metal release and pull up.



For Connecting XTS Adapter to the Radio: Attach bottom of the adapter first, pull back latch, press adapter against radio, release latch. Lock latch with screw.